Condensed operating instructions for extensions (Automatic access to outside line)

Performance feature	Operation
Internal calls	
External calls	
Setting own number for next call	
Temporary disabling of own number transmission	
Forward call with prior notice	
Calling another party during an ongoing call	
Accepting calls	
Accepting a call from an answering machine	
Barring call waiting during an ongoing call	
Accepting call waiting during an ongoing call	
Talking with two parties simultaneously	
Switching between two parties	
Call transfer (ECT)	
Message	
Follow me internal, on	
Follow me internal, off	
Speed dialing	
Configuring call forwarding »immediate«	
Configuring call forwarding »on no answer«	

Do you need other brief operators manuals? The CD delivered with the system contains an operators manual in PDF format (XI521_KBE.PDF). Call up this file and print out the number of copies you need.

Performance feature	Operation
Configuring call forwarding »on busy«	
Deactivating call forwarding »immediate«	
Deactivating call forwarding »on no answer«	
Deactivating call forwarding »on busy«	
Configuring automatic call-back on busy	
Configuring automatic call-back »on no answer«	
Logging in to a team	
Room surveillance	
Project number for next call	
Project number for one call	
Door calls	
Door calls	
Activating the door opener	
Switching contact on	
Switching contact of	
Switching contact for 3 seconds	
Internal signaling function on	
External signaling function on	
Signaling function off	
Deactivating automatic access to outside line	

Deutsche Telekom

Condensed operating instructions for extensions (Making calls with prefixes)

Performance feature	Operation
Internal calls	
External calls	
Setting own number for next call	
Temporary disabling of own number transmission	
Forward call with prior notice	
Calling another party during an ongoing call	
Accepting calls	
Accepting a call from an answering machine	
Barring call waiting during an ongoing call	
Accepting call waiting during an ongoing call	
Talking with two parties simultaneously	
Switching between two parties	
Call transfer (ECT)	
Message	
Follow me internal, on	
Follow me internal, off	
Speed dialing	
Configuring call forwarding »immediate«	
Configuring call forwarding »on no answer«	

Do you need other brief operators manuals? The CD delivered with the system contains an operators manual in PDF format (XI521_KBE.PDF). Call up this file and print out the number of copies you need.

Performance feature	Operation
Configuring call forwarding »on busy«	
Deactivating call forwarding »immediate«	
Deactivating call forwarding »on no answer«	
Deactivating call forwarding »on busy«	
Configuring automatic call-back on busy	
Configuring automatic call-back »on no answer«	
Logging in to a team	
Room surveillance	
Project number for next call	
Project number for one call	
Door calls	
Activating the door opener	
Switching contact on	
Switching contact of	
Switching contact for 3 seconds	
Internal signaling function on	
External signaling function on	
Signaling function off	
Activating automatic access to outside line	